
REMOTE
20
CONTENT
12
16
TV
18
22
10
28
MP
24
17
26
25
REMOV.
MEDIA
32
SHOPPING
COMPUTER
30
MP
(e.g. KIOSK)
INTERNET

Fig. 1


INSERT MEDIA
INTO TV
34
RECORD PROGRAMS
WATCHED, TIMES
TO EST. PROFILE
36
REMOVE
MEDIA
38
INSERT MEDIA
INTO SHOPPING
COMPUTER
40
PRESENT
SHOPPING LIST
FOR USER
SELECTION
44
MATCH TO
AVAILABLE
PRODUCTS
42

Fig. 2